

User Manual

1U LCD Keyboard Drawers 17" and 19" Screen Sizes



ERM Series

- Optical Mouse
- 1U 17" or 19" Screen



ER1-17/19 D/T

- Desktop Style Keyboard1U 17" or 19" Screen

Contents

| Chapter 1 | Get | ting Started |
|-----------|------|---|
| | 1.1 | Important Safeguards1 |
| | 1.2 | Regulatory Notice2 |
| | 1.3 | Package Contents3-4 |
| | 1.4 | Before Installation5 |
| | 1.5 | Unpacking5 |
| | 1.6 | Optional Accessories5 |
| | 1.7 | Peripheral Products6 |
| | 1.8 | Structure Diagram7 |
| | 1.9 | How to Install "One Man" Installation Slides8-9 |
| | 1.10 | How to Use The Slides10 |
| | 1.11 | ER1-17/19M (Single console) |
| | | - Use CE-6 to connect to server via PS/2 interface11 |
| | 1.12 | ER1-17/19M (Single console) |
| | 1 12 | - Use CE-6 to connect to KVM via PS/2 interface |
| | 1.13 | ER1-17/19M-USB (Single console) - Use CE-6 to connect to server via USB interface |
| | 1.14 | ER1-17/19M-USB (Single console) |
| | | - Use CE-6 to connect to KVM via USB interface12 |
| Chapter 2 | One | eration |
| Chapter 2 | 2.1 | On-Screen Display Operation13 |
| | 2.2 | On-Screen Menu |
| | 2.2 | |
| Chapter 3 | Sta | ndard Specification |
| - | 3.1 | Specifications |
| | 3.2 | Keyboard & Mouse16 |
| | | |
| Chapter 4 | • | ional Specification |
| | 4.1 | KVM Options |
| | 4.2 | DVI-D Input Option |
| | 4.3 | BNC+ S-Video Option |
| | 4.4 | Audio Option |
| | 4.5 | Touchscreen Options |
| | 4.6 | DC Power Options19 |
| Chapter 5 | Tro | ubleshooting20 |
| | | |
| Chapter 6 | Dim | nensions21 |

1.1 Important Safeguards

Chapter 1

Please read all of these instructions carefully before you use the device. Save this manual for future reference.

| Any product, on which the serial number has been defaced, modified or removed. |
|---|
| Damage, deterioration or malfunction resulting from: |
| □ Accident, misuse, neglect, fire, water, lightning, or other acts of nature, unauthorized product modification, or failure to follow instructions supplied with the product. |
| ☐ Repair or attempted repair by anyone not authorized by us. |
| ☐ Any damage of the product due to shipment. |
| ☐ Removal or installation of the product. |
| ☐ Causes external to the product, such as electric power fluctuation or failure. |
| ☐ Use of supplies or parts not meeting our specifications. |
| □ Normal wear and tear. |
| ☐ Any other causes which does not relate to a product defect. |
| Removal, installation, and set-up service charges. |

1.2 Regulatory Notice

Chapter 1

Legal Information

First English printing, October 2002

Information in this document has been carefully checked for accuracy; however, no guarantee is given to the correctness of the contents. The information in this document is subject to change without notice. We are not liable for any injury or loss that results from the use of this equipment.

Safety Instructions

- Unplug equipment before cleaning. Don't use liquid or spray detergent; use a moist cloth.
- Keep equipment away from excessive humidity and heat. Preferably, keep it in an air-conditioned environment with temperatures not exceeding 40° Celsius (104° Fahrenheit).
- When installing, place the equipment on a sturdy, level surface to prevent it from accidentally falling and causing damage to other equipment or injury to persons nearby.
- When the drawer is in an open position, do not cover, block or in any way obstruct the gap between it and the power supply. Proper air convection is necessary to keep it from overheating.
- Arrange the equipment's power cord in such a way that others won't trip or fall over it.
- If you are using a power cord that didn't ship with the equipment, ensure that it is rated for the voltage and current labeled on the equipment's electrical ratings label. The voltage rating on the cord should be higher than the one listed on the equipment's ratings label.
- Observe all precautions and warnings attached to the equipment.
- If you don't intend on using the equipment for a long time, disconnect it from the power outlet to prevent being damaged by transient over-voltage.
- Keep all liquids away from the equipment to minimize the risk of accidental spillage. Liquid spilled on to the power supply or on other hardware may cause damage, fire or electrical shock.
- Only qualified service personnel should open the chassis. Opening it yourself could damage the equip ment and invalidate its warranty.
- If any part of the equipment becomes damaged or stops functioning, have it checked by qualified service personnel.

Regulatory Notices Federal Communications Commission (FCC)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

Any changes or modifications made to this equipment may void the user's authority to operate this equipment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.


However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reposition or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

1.3 Package Contents

Chapter 1

For ERM Series




- 1 LCD keyboard drawer x 1 pc
- 2 Power cord x 1 pc
- 3 CE-6 Combo 4-in-1 KVM cable x 1 pc
- 4 User manual (As of Sept 2011, all user manuals will be download-only. Physical copies are available upon request)
- **⑤ WOM-01** Mini USB optical mouse x 1 pc
- 6 Mounting bracket x 2 pcs
- 7 M6*15mm screw x 8 pcs
- 8 M6 cage nut x 6 pcs
- 9 Cup washer x 8 pcs

1.3 Package Contents

Chapter 1

For ER1 D/T Series



- 1 LCD keyboard drawer x 1 pc
- 2 Power cord x 1 pc
- 3 User manual (As of Sept 2011, all user manuals will be download-only. Physical copies are available upon request)
- 4 Auto switch power adapter x 1 pc
- **(5) CE-6** Combo 4-in-1 KVM cable x 1 pc
- 6 Mounting bracket x 2 pcs
- 7 M6*15mm screw x 8 pcs
- 8 M6 cage nut x 6 pcs
- 9 Cup washer x 8 pcs

1.4 Before Installation

Chapter 1

- It is very important to locate the LCD Keyboard Drawer in a suitable environment.
- The surface for placing and fixing the LCD Keyboard Drawer should be stable and level or mounted into a suitable cabinet.
- Make sure the place has good ventilation, is out of direct sunlight, away from sources of excessive dust, dirt, heat, water, moisture and vibration.
- Position LCD Keyboard Drawer with respect to related facilities.

1.5 Unpacking

The LCD keyboard drawer comes with the standard parts shown on the package contents. Check and make sure they are included and in good condition. If anything is missing, or damage, contact the supplier immediately.

1.6 Optional Accessories

1. Combo 4-in-1 KVM cable

- 1.1 CAE-6 (CE-6) 6 fee
- 1.2 CAE-10 (CE-10) 10 feet
- 1.3 CAE-15 (CE-15) 15 feet

2. Power Cord

- 2.1 IEC power cord
- 2.2 NEMA 5-15 power cord (US)
- 2.3 BS 1363 power cord (UK)
- 2.4 CEE 7/4 power cord (German)
- 2.5 AS 3112 power cord (Australia)

3. Wireless USB optical mouse

3.1 WOM-02





Please Note:

■ WOM-02 pertains only to the ERM Series of products

1.7 Peripheral Products


Chapter 1

| Item | Model No. | Description |
|------------------|--|--|
| Matrix Cat6 KVM | 16-Cat6-M2X / M3X / M4X 16-Cat6-M3X-IP / M4X-IP / M4X-2IP 32-Cat6-M2X / M3X / M4X 32-Cat6-M3X-IP / M4X-IP / M4X-2IP | Matrix Cat 6 16-Port KVM Matrix IP Cat 6 16-Port KVM Matrix Cat 6 32-Port KVM Matrix IP Cat 6 32-Port KVM |
| Matrix DB-15 KVM | 8-M2X / M3X / M4X 8-M3X-IP / M4X-IP / M4X-2IP 16-M2X / M3X / M4X 16-M3X-IP / M4X-IP / M4X-2IP | Matrix DB-15 8-Port KVM Matrix IP DB-15 8-Port KVM Matrix DB-15 16-Port KVM Matrix IP DB-15 16-Port KVM |
| Combo Cat 6 KVM | 8-Cat6 / 8-Cat6-2X / 8-Cat6-IP 16-Cat6 / 16-Cat6-2X / 16-Cat6-IP 32-Cat6 / 32-Cat6-2X / 32-Cat6-IP | Combo Cat 6 8-Port KVM Combo Cat 6 16-Port KVM Combo Cat 6 32-Port KVM |
| Combo DB-15 KVM | 8-USB / 8-2X / 8-IP 16-USB / 16-2X / 16-IP | Combo DB-15 8-Port KVM Combo DB-15 16-Port KVM |
| PS/2 DB-15 KVM | 4/8/16 | 4 / 8 / 16-Port PS/2 DB-15 KVM |

1.8 Structure Diagram

Chapter 1


For ERM Series



- ① LCD interchangeable module kit
- ② "One Man" Installation Slide
- 3 LCD membrane
- 4 Microswitch

- (5) Membrane switch (KVM option)
- 6 Mini USB optical mouse
- 7 104 key notepad keyboard with full numberical pad
- 8 Carry handle to release the 2-pt lock

For ER1 D/T Series




- 1 LCD interchangeable module kit
- (2) "One Man" Installation Slide
- 3 LCD membrane

- 4 Full "Unix style" keyboard with numerial pad
- 5 Carry handle to release the 2-pt lock


1.9 How to Install "One Man" Installation Slides

Chapter 1

Install into rack




- Attach the left and right mounting bracket to rack 19" mounting rails.
- Adjust the rear mouting bracket to fit your rack.
- M6 screw and cup washer x 6 pcs included.
- Caution: Leave the screws slightly loose until you complete the installation in step 4




- Pick up the LCD keyboard drawer.
- Insert the LCD keyboard drawer into the mounting bracket.
- Pull and hold the left & right black arrow buttons on the rails.
- Return the LCD keyboard drawer to park position.

1.9 How to Install "One Man" Installation Slides

Chapter 1



- Attach front left and right mounting ears of the LCD keyboard drawer to vertical mounting rails.
- M6 screw and cup washer x 2 pcs included.



Complete the installation

■ Tighten all 8 pcs of M6 screw to complete the installation.

1.10 How to Use the Slides

Chapter 1




Figure 2.

■ Pull and hold the black arrow button on either side of the LCD keyboard drawer to unlock. (shown in **Figure 2**).




Figure 3.

■ Push the LCD keyboard drawer into the rack. (shown in **Figure 3**).



Caution : Keep your fingers away from the slide stop.

1.11 ERM Series (Single Console)

- Use CE-6 to connect to server via PS/2 interface




Figure 4. Example of connecting CE-6 4-in-1 Combo KVM cable to server via PS/2 interface

1.12 ERM Series (Single Console)

- Use CE-6 to connect to KVM via PS/2 interface




Figure 5. Example of connecting CE-6 4-in-1 Combo KVM cable to KVM via PS/2 interface

Please Note:

- ERM Series uses internal power via C13 (ER1 D/T models include an external power brick)
- The above diagrams pertain only to the single console LCD keyboard drawer
- For integrated KVM LCD keyboard drawers, please refer to the "All KVM" user manual



Caution: The LCD keyboard drawer is hot-pluggable, but components of connected devices, such as the servers and KVM switch, may not be hot-pluggable. Plugging and unplugging cables while servers and KVM are powered on may cause irreversible damage of the servers, KVM and LCD keyboard drawer. Before attempting to connect anything to the LCD keyboard drawer, we suggest turning off the power to all devices before connecting them. Apply power to connected devices again only after the LCD keyboard is receiving power. The supplier is not responsible for damage caused in this way.

1.13 ERM Series (Single Console)

- Use CE-6 to connect to server via USB interface




Figure 6. Example of connecting CE-6 4-in-1 Combo KVM cable to server via USB interface

1.14 ERM Series (Single Console)

- Use CE-6 to connect to KVM via USB interface




Figure 7. Example of connecting CE-6 4-in-1 Combo KVM cable to KVM via USB interface


Please Note:

- ERM Series uses internal power via C13 (ER1 D/T models include an external power brick)
- The above diagrams pertain only to the single console LCD keyboard drawer
- For integrated KVM LCD keyboard drawers, please refer to the "All KVM" user manual




Caution: The LCD keyboard drawer is hot-pluggable, but components of connected devices, such as the servers and KVM switch, may not be hot-pluggable. Plugging and unplugging cables while servers and KVM are powered on may cause irreversible damage of the servers, KVM and LCD keyboard drawer. Before attempting to connect anything to the LCD keyboard drawer, we suggest turning off the power to all devices before connecting them. Apply power to connected devices again only after the LCD keyboard is receiving power. The supplier is not responsible for damage caused in this way.

2.1 On-Screen Display Operation



| Membrane Switch | Function |
|--|--|
| 0 | Power light Green = On |
| • | Orange = Power saving |
| | Power on / off LCD |
| M | Display the OSD menu |
| $\diamondsuit \diamondsuit \Leftrightarrow \diamondsuit$ | Scrolls through menu options and adjusts the displayed control (To auto adjustment by pressing the button for 5 seconds) |
| <u></u> | Exit the OSD screen Toggle analog, digital & video connection (DVI-D and video options only) |



OSD Configuration Page

| | Image: To enter into the brighness, contrast, color temp, red, green, and blue |
|------|---|
| | Geometry: To enter into the auto adjust, H position, V position, phase and clock |
| | Video: To enter into the colour, tint, sharpness, noise reduction, DCDi and TV Setup |
| | Audio: To enter into volume, bass, treble, balance, AVL and mute |
| Misc | Misc: To enter into the language, OSD position, graphic mode, ratio, reset and timer |

| Item | Description | | | | |
|-----------------------|--|------------------------------|----------------|---------------------------|--|
| Form Factor | 1U rack mounting on slide-out rails | | | | |
| LCD Manufacturer | SAMSUNG | | | | |
| Mod | ERM-17 | ERM-19 | ER1-17 D/T | ER1-19 D/T | |
| Diagonal Size | 17" TFT | 19" TFT | 17" TFT | 19" TFT | |
| Max. Resolution | 1280 x 1024 | 1280 x 1024 | 1280 x 1024 | 1280 x 1024 | |
| Brightness (cd/m²) | 250 | 250 | 250 | 250 | |
| Color Support | 16.7 M | 16.7 M | 16.7 M | 16.7 M | |
| Contrast Ratio (typ.) | 1000:1 | 1000:1 | 1000:1 | 1000:1 | |
| Viewing Angle (H/V) | 160° x 160° | 160° x 160° | 160° x 160° | 160° x 160° | |
| Display Area (mm) | 338 x 270 | 376 x 301 | 338 x 270 | 376 x 301 | |
| Tr Response Time (ms) | 1.3 | 1.3 | 1.3 | 1.3 | |
| LCD Panel MTBF (hrs) | 50,000 | 50,000 | 50,000 | 50,000 | |
| VGA Signal Input | | Analog RG | BB, 0.7Vp-p | | |
| Sync. Type | | Separate H/V, C | Composite, SOG | | |
| | | 720 x 40 | 00, 70 Hz | | |
| | | 640 x 480, 60/ 70/ 72/ 75 Hz | | | |
| | 800 x 600, 60/ 70/ 72/ 75 Hz | | | | |
| Resolution | 1024 x 768, 60/ 70/ 75 Hz | | | | |
| | 1152 x 864, 60/ 70/ 75 Hz | | | | |
| | 1280 x 720, 60/ 70/ 75 Hz | | | | |
| | 1280 x 1024, 60/ 70/ 72/ 75 Hz | | | | |
| Plug & Play DDC | | EDII | O 1.3 | | |
| Console Port (Combo) | DB-15 connector for VGA / keyboard / mouse (Combo interface) | | | | |
| Power Input | Auto-sensing 100 to 240VAC, 50 / 60Hz | | | | |
| Power Consumption | Max. 48 Watt, Standby 5 Watt | | | | |
| Compatibility | Multi-platform - Mix PCs, SUNs, IBMs, HPs & DELLs. | | | | |
| Regulation Approval | FCC, CE, RoHS | | | | |
| Options | | | | | |
| - | Matrix & combo KVM | with IP console and | | | |
| KVM Integration | 2 console | | | - | |
| Keyboard & mouse | Full size keyb | Full size keyboard built-in | | with touchnad / trackhall | |
| Reyboard & mouse | touch-pad / trackball Desk top size keyboard with touchpad / trackball | | | with touchpad / trackball | |
| Graphic Input | DVI-D, BNC & S-Video input | | | | |
| DC Power | DC power input with 12V, 24V, 48V selection | | | | |
| Touchscreen | Resistive & capacitive | | | | |
| Environmental | | | | | |
| Operation | | 0° to 50° | C Degree | | |
| Storage | -5° to 60°C Degree | | | | |
| Relative Humidity | 5~90%, non-condensing | | | | |
| Shock | 10G acceleration (11ms duration) | | | | |
| Vibration | 5~500Hz 1G RMS random vibration | | | | |

3.2 Keyboard & Mouse

Chapter 3

For ERM Series

■ Standard : WOM-01 Wired mini USB optical mouse

■ Optional : **WOM-02** Wireless optical mouse

■ Multiple keyboard language selections






WOM-01
Wired Mini USB Optical Mouse

Optional:



WOM-02
Wireless USB Optical Mouse

For ER1-17/19 D/T Series



4.1 KVM Options

Chapter 4

Our KVM is designed to seamlessly integrate into the rear of our full range of LCD drawer solutions:

- For KVM operation, please refer to KVM user manual
- Options available for multiple consoles via Matrix KVM
- Options available for high density & cost efficient Combo KVM integration with either 8 / 16 / 32 ports
- Options available for low cost PS/2 KVM
- Please ask your supplier for full KVM details

Please Note:

■ Matrix & Combo KVM options are not available for ER1 D/T models


4.2 DVI-D Option

3-in-1 VGA KB mouse DVI-D console port

ERM-17/19

DVI-D console port

ER1-17/19 D/T



Please Note:

- Package includes 1 x 6ft DVI-D cable
- The depth will be extended from 700mm (27.6") to 750mm (29.5")

4.3 BNC + S-Video Option

ERM-17/19

S-Video

S-Video

BNC

Console port

ER1-17/19 D/T

Please Note:

0


■ Package includes 1 x 6ft S-Video cable

0 0

(....)

4.4 Audio Option

Chapter 4



| | Power | Audio | 3-in-1 VGA KB mouse console port |
|---------------|-------|-------|--|
| ER1-17/19M | [·] | ٥ | () |
| ER1-17/19 D/T | © | • | () |

Please Note:

- Audio input is 35mm audio plug
- The speaker is sharing the same power with LCD.

| Model | 12V | 24V | 48V |
|-----------------|---------|----------|----------|
| Input rating | | | |
| Input voltage: | 12-Volt | 24-Volt | 48-Volt |
| Input range: | 9 ~ 18V | 18 ~ 36V | 36 ~ 75V |
| Input current | | | |
| - No load | 50 mA | 50 mA | 50 mA |
| - Full load | 4950 mA | 2450 mA | 1220 mA |
| Output rating | | | |
| Output voltage: | 12-Volt | 12-Volt | 12-Volt |
| Output current: | 4.16A | 4.16A | 4.16A |
| Efficiency | 84% | 85% | 85% |

Remarks:

- Power cabling is not included with DC Power option
- The depth of ER1-17/19 D/T series will be extended from 700mm (27.6") to 750mm (29.5")

4.6 Touchscreen Options



e-Resistive

| Model | -17TRB / -17TRS | -19TRB / -19TRS |
|-----------------------|---|-----------------|
| Screen size | 17" | 19" |
| Interface | USB / serial | |
| Optical transmittance | 80% ± 3% | |
| Surface hardness | ≥3H (JIS K5400) | |
| Operating system | Windows 98 / 2000 / ME / XP / NT / CE, DOS, Linux | |

e-Capacitive

| Model | -17TCB / -17TCS | -19TCB / -19TCS |
|-----------------------|--|-----------------|
| Screen size | 17" | 19" |
| Interface | USB / serial | |
| Optical transmittance | 93% ± 2% | |
| Surface hardness | >9H Surface hardness, withstand over 300 million touches | |
| Operating system | Windows 98 / 2000 / ME / XP / NT / CE, DOS, Linux | |

Please Note:

- The height of ERM-17/19 & ER1-19 D/T will be increased from 1U to 1.5U
- USB touchscreen package includes 1 x 6ft USB cable, quick reference guideline and CD disc
- Serial touchscreen package includes 1 x 6ft serial cable, quick reference guideline and CD disc
- For detailed information, please refer to the CD disc included with the touchscreen
- As the touchscreen unit is not made of toughened glass, please handle it carefully
- Touchscreens in other brands are available on request

5.1 Troubleshooting

Chapter 5

1. How do I adjust the resolution?

To change monitor resolution, click Start -> Control Panel -> Display. Select Setting tab to adjust the monitor resolution in Desktop Area. The available resolutions, "640 x 480", "800 x 600", "1024 x 768", "1152 x 864", "1280 x 1024", are determined by the display card in your computer.

2. Is interference signal appeared on LCD normal when shutting down the computer?

In rare cases, interference may appear on the monitor. This may be caused by signal rate of VGA card and is considered normal. The image quality can be improved by adjusting the phase or pixel rate automatically or manually.

3. The membrane power light is not lit?

Press the power On / Off on LCD membrane to check if the monitor is in the ON mode. Check the power cord is properly connected to the LCD keyboard drawer and power outlet.

4. Screen image is not centered or sized properly

Press the button for two seconds to automatically adjust the image. Adjust the H-position and V-position settings via On-screen menu.

5. Is the LCD keyboard drawer hot-pluggable?

The LCD keyboard drawer is hot-pluggable, but components of connected devices such as the servers and KVMs may not be hot-pluggable. We suggest turning off the power to all devices before connecting them. Apply power to connected devices again only after the LCD keyboard receives power.

6.1 Dimensions Chapter 6

| Model | Product Dimension | Packing Dimension | Net | Gross |
|---------------------|---------------------|--------------------|--------|--------|
| | (W x D x H) | (W x D x H) | Weight | Weight |
| E R M-17 | 442 x 650 x 44 mm | 589 x 826 x 168 mm | 17 kg | 23 kg |
| | 17.4 x 25.6 x 1.73" | 23.2 x 32.5 x 6.6" | 37 lb | 51 lb |
| E R M-19 | 442 x 700 x 44 mm | 589 x 856 x 168 mm | 18 kg | 24 kg |
| | 17.4 x 27.6 x 1.73" | 23.2 x 33.7 x 6.6" | 40 lb | 53 lb |
| E R 1-17 D/T | 442 x 700 x 44 mm | 589 x 856 x 168 mm | 18 kg | 24 kg |
| | 17.4 x 27.6 x 1.73" | 23.2 x 33.7 x 6.6" | 40 lb | 53 lb |
| E R 1-19 D/T | 442 x 700 x 44 mm | 589 x 856 x 168 mm | 19 kg | 25 kg |
| | 17.4 x 27.6 x 1.73" | 23.2 x 33.7 x 6.6" | 42 lb | 55 lb |

The company reserves the right to modify product speci cations without prior notice and assumes no responsibility for any error which may appear in this publication.

All brand names, logo and registered trademarks are properties of their respective owners.

Copyright 2010 Austin Hughes Electronics Ltd. and Eclipse Rackmount, Inc. All rights reserved.

P.21 ML07V01A